

wireless solution

W-DMX Quick Start Guide

1.

Make all signal and power connections to transmitter and receivers.

(NOTE: If utilizing more than one universe, the first universe must be powered and synchronized separately. After it has synchronized you may leave it connected while adding any additional universes.)



2.

Press and quickly release the function button on the transmitter.

3.

The transmitter will start flashing rapidly red/green scanning for new free receivers.

4.

After approximately 10 seconds the transmitter will jump back to normal mode and continue transmitting data.

5.

The receivers are now automatically synchronized to the transmitter.

Transmitter, Status LED

Light	What Does It Mean?
Flashing red/green	No DMX connected
Solid green	DMX signal detected and transmitted
Fast flashing red/green	Log in mode (every free receiver, not logged in to any other transmitter, will be logged on)

Receiver, Status LED

Light	What Does It Mean?
Solid red	Not logged on to a transmitter (free)
Flashing green ~ 1 seconds / red ~0-1 seconds	Logged on to a transmitter and DMX line idle
Solid green	Logged on to a transmitter and receiving DMX data.

- Note:**
1. To clear ALL receivers and restart, press and hold the TRANSMITTER function button for 3-4 seconds.
2. To clear a SINGLE receiver into idle mode, press and hold that RECEIVER function button for 3-4 seconds.

Creative Stage Lighting Co., Inc.

North Creek, NY USA • Phone: (518) 251-3302

Mon - Fri 8:30am - 5:00pm EST

E-Mail: info@creativestagelighting.com

<http://www.creativestagelighting.com>

